



FITTING INSTRUCTIONS

Part Number :- 501084
Part Description :- Ace Mounting
Fitting Location :- Right Mount



Make	Model	Bodystyle	From	To
Ford	Transit	Van	7/2006	3/2014

Vehicle Details

Ford Transit Van 7/2006 - 3/2014

Instructions

1. Using a trim removal tool carefully unclip and remove the right lower dashboard trim located below the steering column.
2. Unclip and remove the small rectangular air-vent trim located in front of the right cupholder.
Note: The air-vent trim slides sideways towards the driver's door when it is removed.
3. Unclip and remove the top section of the right cupholder trim.
4. Remove the Six Philips screws securing the right dashboard end panel trim, then carefully unclip and remove the trim panel.
5. Position the bracket at the end of the dashboard until the bracket fixing hole aligns with the top screw hole (See Image)
6. Refit the dashboard end panel trim back into position over the top of the bracket and then secure both the bracket and the dashboard end cap trim in position using the 6 Philips screws.
7. Refit the right lower dashboard trim.
8. Refit the top section of the right cupholder trim.
9. Finally refit the small rectangular air-vent trim.



Care should always be taken by the installer when installing this product. Nemesis is not liable for any damage caused to a vehicle by incorrect installation, use, modifications or repair by any 3rd party or yourself.
Tel: 01905 720199 email: sales@nemesis.ltd web: www.nemesisb2b.com