



FITTING INSTRUCTIONS

Part Number :- 501281
Part Description :- Ace Mounting
Fitting Location :- Left Dash



Make	Model	Bodystyle	From	To
Renault	T460	HGV	1/2015	Onw

Vehicle Details

Renault T460 HGV 1/2015 - Onw

Instructions

- 1.) Unclip and remove the fuse box cover from the top of the dashboard.
- 2.) Remove the Two T20 Torx screws that secure the dashboard top trim panel located above the parking brake / heater controls, then using a trim tool carefully un-clip and remove the trim panel.
- 3.) Remove the T20 Torx screw from the top of the dashboard side panel that is positioned to the Left of the Two air-vents, then using the trim tool carefully un-clip and remove the side panel.
- 4.) Locate the bracket against the dashboard sub-structure on the left side of the dashboard, so the bracket is position directly to the left side of the upper air-vent.
- 5.) Drill two small 2mm pilot holes through the Two bracket holes into the dashboard sub-structure, then using the Two self-tapping screws provided secure the bracket firmly in position.
- 6.) Finally refit the dashboard side panel, top trim panel and the fuse box cover.



Care should always be taken by the installer when installing this product. Nemesis is not liable for any damage caused to a vehicle by incorrect installation, use, modifications or repair by any 3rd party or yourself.
Tel: 01905 720199 email: sales@nemesis.ltd web: www.nemesisb2b.com