



FITTING INSTRUCTIONS

Part Number :- 501129
Part Description :- Ace Mounting
Fitting Location :- Left Dash



5055167732184

Make	Model	Bodystyle	From	To
Iveco	Stralis Hi Way (AS)	HGV	1/2014	1/2020

Vehicle Details

Iveco Stralis Hi Way (AS) HGV 1/2014 - 1/2020

Instructions

1. Using a trim removal tool carefully unclip the heater control surround trim that holds the vehicle power socket.
2. Position the bracket in the channel to the left side of where the power socket is located so the bracket is positioned in between the two steel spring clips that hold the heater control surround trim in position.
3. Check there are no wires behind the plastic trim and then using a 5.5mm diameter drill bit, drill through the two bracket mounting holes.
4. Using the 2 x M5x12 mm Machine screws and the 2 x M5 Nylon Nuts provided, secure the bracket firmly to the dashboard.
5. Finally replace the heater control surround trim.



Care should always be taken by the installer when installing this product. Nemesis is not liable for any damage caused to a vehicle by incorrect installation, use, modifications or repair by any 3rd party or yourself.
Tel: 01905 720199 email: sales@nemesis.ltd web: www.nemesisb2b.com