



FITTING INSTRUCTIONS

Part Number :- 501367
Part Description :- Ace Mounting
Fitting Location :- Right Mount



Make	Model	Bodystyle	From	To
Toyota	HiLux 4x4	2/4 Door Pick-up	2/2010	1/2016
Toyota	HiLux 4x4	2/4 Door Pick-up	10/2005	1/2010

Vehicle Details

Toyota HiLux 4x4 2/4 Door Pick-up 10/2005 - 1/2010

Instructions

1. Carefully pull and remove the O/S/F door seal, in the area adjacent to the dashboard end and the right "A" Pillar trim.
2. Using a trim removal tool carefully un-clip the Two screw caps on the right "A" pillar grab handle, and then remove the grab handle using a Philips screwdriver.
3. Unclip and remove the right "A" pillar trim, then remove the 10mm bolt located at the base of the "A" pillar where the trim was removed.
4. Using the Philips screwdriver remove the plastic clip at the top of the instrument binnacle surround trim just above the speedometer, then unclip and remove the surround trim.
5. Carefully slide the bracket into position starting from the top downwards into the void where the "A" pillar trim was removed, then carefully pull the dashboard towards you slightly opening a small gap before sliding the bracket upwards again until it fits in between the plastic of the dashboard and the metal bracket that the bolt secures into.
6. Align the bracket with the bolt hole and then re-install the bolt leaving it slightly loose.
7. Stretch the left side of the bracket over the edge of the dashboard where the instrument binnacle surround trim was removed until the bracket rests against the front of the dashboard.
8. Once the bracket is located tight against the dashboard, drill through the hole on the left edge of the bracket into the dashboard sub-structure using a 5mm drill bit.
Note: This hole will be hidden by the instrument binnacle surround trim when it is re-installed.
9. Use a pot rivet gun to secure the left side of the bracket to the dashboard with the pot rivet provided.
10. Re-install the instrument binnacle surround trim and the plastic clip.
11. Check and adjust the alignment of the bracket and then tighten the 10mm bolt to secure it firmly in position.
12. Re-install the "A" pillar trim, grab handle and the screw covers.
13. Finally re-install the O/S/F door seal.



Care should always be taken by the installer when installing this product. Nemesis is not liable for any damage caused to a vehicle by incorrect installation, use, modifications or repair by any 3rd party or yourself.
Tel: 01905 720199 email: sales@nemesis.ltd web: www.nemesisb2b.com